

The Watson hands-free mobile microphones are designed for use with most radios. However, as there are so many different combinations of wiring, some of the extra functions, over and above the PTT and audio level controls, may not work on some radios.

RADIO	UNIT	LEAD	COMMENTS
FT-8900R	WM-S-FT	SUPPLIED	PTT, Audio level, Up/Down and 4-functions. NOTE: Must change microphone menu item to "MH-42" for functions drawing A.
FT-8800E	WM-S-FT	SUPPLIED	PTT, Audio level, Up/Down and 4-functions. NOTE: Must change microphone menu item to "MH-42" for functions drawing A.
FT-7800E	WM-S-FT	SUPPLIED	PTT, Audio level, Up/Down and 4-functions. NOTE: Must change microphone menu item to "MH-42" for functions drawing A.
FT-1500M	WM-S-FT	SUPPLIED	PTT, Audio level only. No Mic. menu item.
FT-2800M	WM-S-FT	SUPPLIED	PTT, Audio level, Up/Down and 4-functions. NOTE: Must change microphone menu item to "MH-42" for functions drawing A.
FT-1802E	WM-S-FT	SUPPLIED	PTT only. No Up/Down. No menu option.
FT-100	WM-S-FT	SUPPLIED	PTT, Audio level, Up/Down, Channel change
FT-817ND	WM-S-RW	WYL-8M	PTT, Audio level & Up/Down
FT-857D	WM-S-RW	WYL-8M	PTT, Audio level & Up/Down
TM-V7E	WM-S-RW	WKL-8M	PTT, Audio level & Up/Down
TM-271E	WM-S-RW	WKL-8M	PTT, Audio level & Up/Down
TM-D700E	WM-S-RW	WKL-8M	PTT, Audio level & Up/Down
TM-G707E	WM-S-RW	WKL-8M	PTT, Audio level & Up/Down
IC-2200H	WM-S-IC	WIL-8M	PTT, Audio level & Up/Down
IC-E208	WM-S-IC	WIL-8M	PTT, Audio level & Up/Down
IC-2100H	WM-S-IC	WIL-8M	PTT, Audio level & Up/Down
IC-2725E	WM-S-IC	WIL-8M	PTT, Audio level & Up/Down
IC-706MKIIGSP	WM-S-RW	WIL-8M	PTT, Audio level & Up/Down
IC-7000	WM-S-7000	WIL-8M	PTT, Audio level & Up/Down (lead end marked Radio to go to radio)
DX-70TH	WM-S-RW	WKL-8R	PTT, Audio level & Up/Down
DX-77	WM-S-RW	WKL-8R	PTT, Audio level & Up/Down
DR-135EMKII	WM-S-RW	WKL-8R	PTT, Audio level & Up/Down * See Note
DR-605E	WM-S-RW	WKL-8M	PTT, Audio level & Up/Down * See Note
DR-435E	WM-S-RW	WKL-8R	PTT, Audio level & Up/Down * See Note
DR-635E	WM-S-RW	WKL-8R	PTT, Audio level & Up/Down
DR-M06TH	WM-S-RW	WKL-8R	PTT, Audio level & Up/Down
DR-M03TH	WM-S-RW	WKL-8R	PTT, Audio level & Up/Down

Re-issued 28/06/07

* Note: Insert microphone plug, turn on radio, turn off radio, turn on radio again.